Introduction on how to use the handheld as a FTP client to connect the FTP server

Premise: ensure that the handheld and FTP server on the same network segment.

1. Install ARMV4_FTPClient or ARM_FTPClient tool to the handheld, then open FTPClient tool, as the following Pic;



2. Input the IP address of the FTP server within the address bar, and also for the ID and password, then click' Connect';
3. Then you can connect to the FTP server and upload or download the sources;